



TYPICAL SECTION
NOT TO SCALE

- NOTE: 1. DEPTH OF BALLAST SECTION WILL DEPEND ON SUBGRADE STRENGTH, TRAFFIC DENSITY AND WHEEL LOADS.
2. MINIMUM DEPTH OF BALLAST IS 10 INCHES BELOW THE BOTTOM OF THE TIE AT THE LOW (INSIDE) RAIL OF THE CURVE.
3. ON CURVES OF 6 DEGREES OR GREATER A BALLAST SHOULDER WIDTH OF 8 INCHES SHOULD BE USED.
4. CUT AND FILL ACCORDING TO LOCAL CONDITIONS.

REFERENCE: TM 5-850-2/AFM 88-7, CHAPTER 2, RAILROAD DESIGN AND CONSTRUCTION OF ARMY AND AIRFORCE INSTALLATIONS.

TYPICAL BALLAST SECTION - CURVES	DATE AUG 1992	FIGURE 2-36c
----------------------------------	------------------	-----------------